

Cleanroom Adhesive Mats

Applications: Cleanroom, microelectronics, medical, printing, general maintenance.



Adhesive Mats are made of thin layers of adhesive coated polyethylene film. These tacky layers remove particulates from shoes and cart wheels with each entry to the cleanroom. Mats are designed to resist adhesive transfer, preventing sheet-to-sheet delamination. This safety feature reduces any risk of worker related tripping and allows for carts to roll over the mat easily. To prevent distortion and slippage, the adhesive backing secures the mat to the floor.

Each mat has thirty numbered, removable sheets for quick and easy maintenance. Each number tab is a yellow film which is sealed to each adhesive sheet eliminating the introduction of particulate matter which could occur if the mat is number stamped. The edges are not beveled to ensure that each sheet is contaminate free and give you the highest possible surface area over each sheet. Mats come in a variety of sizes and three colors – blue, grey and white. Custom sizes and beveled edge are also available.

Specifications

- Class-100 compatible
- 30 or 60 pull-away sheets per mat
- Resistant to adhesive transfer
- Resistant to sheet-to-sheet delamination
- Available in white and blue
- Water based adhesive
- Four 30-sheet mats per case or eight 30-sheet or eight 60-sheet mats per case

Product No.	Size	Color	QTY/CASE
HC-SM1836-120	18"x36"	Blue/White	120
HC-SM1845-120	18"x45"	Blue/White	120
HC-SM1845-240	18"x45"	Blue/White	240
HC-SM1845-480	18"x45"	Blue/White	480
HC-SM2645-120	26"x45"	Blue/White	120
HC-SM2645-240	26"x45"	Blue/White	240
HC-SM2645-480	26"x45"	Blue/White	480

Distribute by: